


GZ Series safe on-off valve





Ordering code



①Model	②Port size	3Accessories	4 Thread type	
GZ200: 200 Series soft on-off valve	06: 1/8" 08: 1/4"	Blank: Bracket		
GZ300: 300 Series soft on-off valve	08: 1/4" 10: 3/8" 15: 1/2"	J: No bracket(standard	T: NPT	
GZ400: 400 Series soft on-off valve	10: 3/8" 15: 1/2"	configuration)		

Note: When it is used with F.R.L. combination, extra mounting bracket needed.

Specification


Model	GZ200-06	GZ200-08	GZ300-08	GZ300-10	GZ300-15	GZ400-10	GZ400-15					
Fluid	Air											
Port size [Note1]	1/8"	1/4"	1/4"	3/8"	1/2"	3/8"	1/2"					
Exhaust port size	1/	4"		3/8"	1/2"							
Acting type	Manual											
Valve type	3 port 2 way											
Pressure range		0~1.0MPa(0~145psi)										
Proof pressure	1.5MPa(215psi)											
Temperature range	−20~70°C											
Operation angle	90°											
Suitable F.R.L type	GC200-06	GC200-08	GC300-08	GC300-10	GC300-15	GC400-10	GC400-15					

[Note1] NPT thread is available.

Product feature

- ${\bf 1.}\ It\ is\ module\ design\ and\ can\ be\ used\ with\ G\ series\ F.R.L.\ combination\ by\ bracket.$
- 2. This valve can be used as manual 3/2 way valve.
- 3. Visual indication marked EXH/SUP.
- 4. This valve meets the standard on installation conducted by operator specified by OSHA(Occupational Safety & Health Administration). When the machinery is maintained and serviced, the purge valve (Safe on-off valve) for remaining pressure shall be used to eliminate the remaining pressure when the air source is cut off. Valve must be locked to prevent accidental operation by a third party during maintenance. This prevents accidental system pressurization & cylinder actuation which can result in injuries to the machine operator.


During Maintenance






GZ Series safe on-off valve


Inner structure




No.	Item	No.	Item	No.	Item
1	Valve cap	6	Fixing plate	11	Plug
2	Body	7	pin	12	Spring
3	Screw	8	O-ring	13	O-ring
4	Operating screw	9	Cover	14	Cover
5	Adjusting screw	10	Spool		

Dimensions







[Unit: mm]

Α	AB	В	BA	ВС	BD	С	K	KA	KB	KC	P	PA	Q	
47	42	E2 6	20	40	42 E	90		27	0 E	22	1/8"	26 5	1/4"	
47	42	52.0	30	40	42.5	09	5.5	2/	0.5	23	1/4"	30.5	1/4"	
											1/4"		3/8"	
60	55	70.7	41	53.5	56.5	112.5	6.5	40	8	27	3/8"	46	3/8"	
												1/2"		3/8"
75	6.5	02.0	F0	6.4	6.6	124	0.5		11	22 5	3/8"	F0 F	1/2"	
	05	63.9	50	04	00	134	0.5	35	11	33.5	1/2"	56.5	1/2"	
	47 60	47 42 60 55	47 42 52.6 60 55 70.7	47 42 52.6 30 60 55 70.7 41	47 42 52.6 30 40 60 55 70.7 41 53.5	47 42 52.6 30 40 42.5 60 55 70.7 41 53.5 56.5	47 42 52.6 30 40 42.5 89 60 55 70.7 41 53.5 56.5 112.5	47 42 52.6 30 40 42.5 89 5.5 60 55 70.7 41 53.5 56.5 112.5 6.5	47 42 52.6 30 40 42.5 89 5.5 27 60 55 70.7 41 53.5 56.5 112.5 6.5 40	47 42 52.6 30 40 42.5 89 5.5 27 8.5 60 55 70.7 41 53.5 56.5 112.5 6.5 40 8	47 42 52.6 30 40 42.5 89 5.5 27 8.5 23 60 55 70.7 41 53.5 56.5 112.5 6.5 40 8 27	47 42 52.6 30 40 42.5 89 5.5 27 8.5 23 1/8" 60 55 70.7 41 53.5 56.5 112.5 6.5 40 8 27 3/8" 75 65 83.9 50 64 66 134 8.5 55 11 33.5	47 42 52.6 30 40 42.5 89 5.5 27 8.5 23 1/8" / 1/4" / 36.5 60 55 70.7 41 53.5 56.5 112.5 6.5 40 8 27 3/8" / 1/2" / 3/8" / 1/2" 75 65 83.9 50 64 66 134 8.5 55 11 33.5 3/8" / 58.5	